





	A	B	C	D	E	F	G	H
UE58AU71**	1291,0 mm (1291.0 mm)	748,6 mm (748.6 mm)	59,9 mm (59.9 mm)	824,3 mm (824.3 mm)	250,2 mm (250.2 mm)	146 cm (146 cm)	15,2 кг (15.2 kg)	15,4 кг (15.4 kg)
UE65AU71**	1449,4 mm (1449.4 mm)	830,3 mm (830.3 mm)	59,9 mm (59.9 mm)	906,6 mm (906.6 mm)	282,1 mm (282.1 mm)	163 cm (163 cm)	20,6 кг (20.6 kg)	20,9 кг (20.9 kg)
UE70AU71**	1556,2 mm (1556.2 mm)	899,3 mm (899.3 mm)	60,5 mm (60.5 mm)	988,1 mm (988.1 mm)	341,1 mm (341.1 mm)	176 cm (176 cm)	24,8 кг (24.8 kg)	25,3 кг (25.3 kg)
UE75AU71**	1673,2 mm (1673.2 mm)	958,2 mm (958.2 mm)	59,9 mm (59.9 mm)	1047,9 mm (1047.9 mm)	341,1 mm (341.1 mm)	189 cm (189 cm)	30,4 кг (30.4 kg)	30,8 кг (30.8 kg)

*: 0~9, A~Z



	VESA A x B (mm) VESA A x B (mm)	C (mm) C (mm)	D x 4
UE58AU71**	400 x 300	20-22	M8
UE65AU71**			
UE70AU71**			
UE75AU71**	400 x 400		

*: 0~9, A~Z


SAMSUNG

Краткое руководство по установке
QUICK SETUP GUIDE

Жылдам орнату нұсқаулығы

Короткий посібник зі встановлення
O'rnatish bo'yicha qisqacha qo'llanma


AU71** 58"-75"



BN68-12301B-01




Не касайтесь экрана
Do not touch the screen
Не торкайтесь екрану
Экранды тимеңіз
Ekranga tegmang







		USB
		OPTICAL
		HDMI (eARC)
		HDMI
		LAN
		ANT




1



2



3



4

